



The **Edit Log** screen can update/correct the driver's or driving duty data entries logged through the HOS app. It can also view the history of an edited log.



1. **Daily Driver's Log Chart:** Touch the driver's log chart to start editing it.



2.

- You can navigate through the daily driver logs by selecting either the




Previous Day or





Next Day Button.

- You can also view the cycle used and the Starting Hour of the day set by the carrier which is placed just above the grid chart
- By default, secondary events are not displayed and only primary events can be viewed in the Event History List.



- You can show all events by tapping the Show All Events option.





Status	Start	Duration	Location	Note	+ EXCEPT	+ ADD
1 OffDuty	12:00 AM	13h 54m				
2 Login	08:50 AM			Driver Login		✎ EDIT
3 OffDuty	01:54 PM	1h 05m				✎ EDIT
4 Logout	01:54 PM			Driver Logout		✎ EDIT
5 Login	02:49 PM			Driver Login		✎ EDIT
6 Power On	02:59 PM			Automatic Transition		✎ EDIT
7 Miss Diag	02:59 PM			Missing: Location		✎ EDIT
8 Driving	03:00 PM	8h 59m		Automatic Transition 30		✎ EDIT
9 Miss Diag	03:00 PM			Missing: Location		✎ EDIT

+Inactive: IC=Changed, ICR=Change Requested, ICJ= Change Rejected



- You can add new events by tapping the **Add Events Button**. The **Create Event Pop-up Dialog** will then appear where you can input the details of the new event.

Create Event for Thu Mar 23

Start: <-15 Thu 12:03 PM +15>

Duration: 0 minutes

Status: OffDuty ▾

Location:

Note:

Reason: No reason selected ▾

Odometer: mi

Personal Use Yard Moves

CANCEL **OK**





- **Notes:**
 - The current status of the app is disabled to prevent adding the same status consecutively.
 - The backward and forward time arrows are being disabled to prevent time from going before or after the current day. (eg. 12:00AM – 11:59PM)



- Select the **Edit Log Button** of the driver log event that you wish to edit.

6	DRIVING	12:06 PM	01m	55 Water St., New York, NY 10004	equipment delivery	 Edit
---	---------	----------	-----	--	-----------------------	---

- **Note:** The Edit Log Button will show **NOTE** instead of **Edit** because the driver will only be able to add a note to the following events:
 - Intermediate log
 - Login/logout
 - CMV Engine power up/shut down
 - Malfunctions and diagnostic events

17	Pos MF	02:24 PM				 NOTE
18	Power Off	02:24 PM		Automatic Transition		 NOTE
19	Miss Diag	02:24 PM		Missing: Location		 NOTE
20	Inter	02:24 PM		Automatic Transition		 NOTE

- **The Modify Event pop-up dialog will then appear.**

Modify Event for Thu Mar 23 log

Start: <-15 Thu 11:20 AM +15>

Duration: 1 minutes

Status: Driving ▾

Location: Enter Location

Note: Add Note

Reason: No reason selected ▾

Odometer: 0 mi

Personal Use Yard Moves

CANCEL OK

-
- You can update the duty status from the **Status Drop-down List**.

Status: Driving ▾

-
- You can also manually update the **Location** field.


Location: 55 Water St., New York, NY 10014

-
- You may fill in the **Note** field for your notes or remarks.


Note: equipment delivery

■

- In creating or editing an event status, the ELD requires annotations to be 4 characters or longer, including embedded spaces if driver annotation is required and driver is prompted by the ELD. If the driver enters an annotation with less than 4 characters then a warning dialog will prompt the driver.



- Tap **Reason** dropdown selection to select a reason for updating the log.



■

Modify Event for Thu Mar 23 log

Start: <-15 Thu 11:20 AM +15>

Duration: 1 minutes

Status: Driving ▾

Location: Enter Location

Note: Add Note

Reason: No reason selected ▾

Odometer:




DEACTIVATE

11:21 AM	36m
11:36 AM	
11:38 AM	

- **Note:** Adding/Editing a current/previous record should not require a reason or a note, However, if a record is being added/edited in the previous logs then the Note field should not be empty and must contain at least 4 characters.
- You may fill in the **Odometer** field for your odometer value.

Odometer: Mi


Note: When the Odometer value was supplied for a previous driving status the value entered is carried over to the new driving status when making a status change. Hence, the Odometer value entered for the current day will set as the Begin Odometer value.

- Touch the  **OK Button** to save the changes you made to the duty status event.
- You can select the  **Cancel Button** to cancel the updates to the said duty status or
- the  **Delete Button** to delete the said event.

Created Events

Upon logging in and logging out of the HOS app, as well as connecting and disconnecting to a VBUS Device, new event types will display on the Event History List. The New Event Types are as follows:

- Certify
- Remark – with a note of “Authenticate” (if logging in) or “Unauthenticate” (if logging out)
- ELD Login – event that will be recorded when app is connected to VBUS Device
- ELD Logout – event that will be recorded when app is disconnected to VBUS Device




Note: Auto events created are recorded in the app with a note stating: “**Automatic Transition**”

- **Personal Conveyance** – If this is enabled, the status will be set to Off Duty automatically and will disable the Yard Moves checkbox. Selection of this option will be recorded within the events history list.
- **Yard Moves** – If this is enabled, the status will be set to On Duty automatically and will disable the Personal Conveyance checkbox. Selection of this option will be recorded within the events history list.


Note: In addition, not all of the events statuses are displayed on the grid chart. **Personal Conveyance** is represented by a **dashed line** while **Yard Moves** is represented by a **dotted line** to be visually different with the other event statuses displayed on the grid chart. The Personal Use and Yard Moves legends will only display below the grid chart when the options were set/enabled. A driver’s indication that the CMV is being operated for authorized personal purposes may span more than one CMV

ignition on cycle if the driver proactively confirms continuation of the personal use condition prior to placing the vehicle in motion when the ELD prompts the driver at the beginning of the new ignition power on cycle.



View Log

Start Time: 00 Tue May 23, 2017 US70hr8days



Violation: none Exception: none
 Co-Drivers: Bryan Vega Show all events

Status	Start	Duration	Location	Note	+ EXCEPT	+ ADD
1 Yard Moves	00:00	5h 00m				EDIT
2 ClearYM	05:00					EDIT
3 Sleeper	05:00	1h 45m				EDIT
4 Personal Use	06:45	5h 15m				EDIT
5 Remark	11:58			Authenticate		EDIT
6 Remark	12:00			Co-driver logged in: Bryan Vega		EDIT

+Inactive: IC=Changed, ICR=Change Requested, ICJ= Change Rejected

Note: If the Admin edits the Driver logs, the Driver must first review and accept the changes for them to apply to apply to the Certified Logs. If this does not appear after the Admin has makes the edit, log out and back into the ELD.

